

Requirement of Employers when Planning Work in Proximity to the Energized 600 VDC Trolley Overhead System

Qualified Independent Safety Watch is required during all Craning, Booming, Concrete Pumping, Loading, Unloading, Scaffold erection and dismantles activity. (in close proximity to our Power System as detailed in the attached documents)

In regards to the Qualified Independent Safety Watch, leaving the Safety Watching requirement up to the individual Developers/General Contractors/Construction Companies, etc., has not been affective over past years, and has made it impossible for us to ensure compliance, consistency, accountability, and control over our Power System. To ensure that we have control, stability, and accountability, all Independent Qualified Safety Watch requirements will be facilitated through an existing Utility Supplier to TransLink/CMBC (TC).

You may contact TC Utility Services, an Authorized TOH Power System provider of Qualified Safety Watch @ 1-604-425-1421. (Confirmation of Safety Watch being put in place with TC Utility Services is required prior to work beginning). If TC is unable to supply then Rokstad Power or Allteck will also provide independent qualified safety watch.

